

TRACK AND FIELD

TABLE OF CONTENTS

I.	GENERAL INFORMATION:	PAGE	NO.
	USER INFORMATION	_	
	INTRODUCTION & NOTES		
	GAME PLAY INSTRUCTIONS	3	
II.	OPERATION:		
	GAME OPTIONAL DIP SWITCH SETTINGS	4	
	INSTALLATION & ELECTRICAL REQUIREMENTS	6	
	110/220 VAC CONVERSION INSTRUCTIONS	7	
	110/220 VAC INTERCONNECT DIAGRAM (FIG.1)	8	
	ROUTINE MAINTENANCE & SERVICE, POWER SUPPLY	9	
III.	GAME PARTS DRAWINGS, PARTS LISTS & SCHEMATICS:		
	CABINET FRONT VIEW, (FIG.2)	10	0
	CABINET FRONT VIEW PARTS LIST	1	1
	COIN DOOR ASS'Y, EXPLODED VIEW (FIG.3)	13	2
	COIN DOOR ASS'Y PARTS LIST	13	3
	POWER SUPPLY PSR-703-AE SCHEMATIC (414-2020)	1	4
	POWER SUPPLY PSR-703-AE PARTS LIST	1!	5
	CPU WIRE HARNESS, TRACK & FIELD (FIG. 5)		
	CONTROL PANEL WIRE HARNESS (FIG. 6)	18	3
	SCHEMATICS		

USER INFORMATION - F.C.C.

WARNING

THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS MANUAL, MAY CAUSE INTERFERENCE TO RADIO COMMUNICATIONS.

IT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" COMPUTING DEVICE PURSUANT TO SUBPART J OF PART 15 OF F.C.C. RULES, WHICH ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST SUCH INTERFERENCE WHEN OPERATED IN A COMMERCIAL ENVIRONMENT.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE INTERFERENCE IN WHICH CASE THE USER AT HIS OWN EXPENSE WILL BE REQUIRED TO TAKE WHATEVER MEASURES MAY BE REQUIRED TO CORRECT THE INTERFERENCE.

INTRODUCTION

"TRACK & FIELD IS A MICROPROCESSOR BASED COIN-OPERATED ELECTRONIC GAME, THAT MAKES EXTENSIVE USE OF DIGITAL INTEGRATED CIRCUITRY AND TELEVISION MONITOR CONCEPTS. THIS MANUAL IS DESIGNED FOR THE USE OF MAINTENANCE TECHNICIANS WHO POSSESS A GENERAL KNOWLEDGE OF SOLID-STATE CIRCUITRY AND VIDEO MONITOR THEORY. ANY INDIVIDUAL NOT KNOWLEDGEABLE IN THESE AREAS SHOULD NOT ATTEMPT REPAIR OF THE ELECTRONIC PORTIONS OF THE GAME.

IN ADDITION TO THIS MANUAL AND TRAINING IN ELECTRONICS, TROUBLE-SHOOTING AND REPAIR WILL BE FACILITATED BY ACCESS TO GENERAL-TYPE HANDTOOLS, A MULTIMETER, A 50 OR 100 MHz OSCILLOSCOPE AND A LOGIC PROBE WOULD BE HELPFUL.

TECHNICAL ASSISTANCE IS AVAILABLE BY CALLING (305) 558-5200 OR OUR TOLL FREE LINE LISTED BELOW.

QUESTIONS OR COMMENTS CONCERNING "TRACK & FIELD" OR ANY OF OUR GAMES ARE WELCOME AND SHOULD BE DIRECTED TO:

CENTURI, INC.

CUSTOMER SERVICE DEPARTMENT #800-327-7710 (OUTSIDE THE STATE OF FLA.)

NOTES

NEVER REPLACE ANY COMPONENT WITH ANYTHING OTHER THAN THE EXACT REPLACEMENT PART.

NEVER REMOVE CIRCUIT BOARD CONNECTIONS WHILE POWER IS ON.

DO NOT REPLACE A FUSE WITH ANYTHING OTHER THAN THE PROPER VALUE.

A BLOWN FUSE INDICATES AN OVERLOAD CONDITION WITHIN THE GAME.

REPLACING A FUSE WITH A HIGHER VALUE CAN CAUSE SEVERE DAMAGE TO INTERNAL COMPONENTS IF AN OVERLOAD OCCURS.

ALWAYS CONSULT THE SERVICE MANUAL BEFORE ATTEMPTING REPAIRS.

PLAY INSTRUCTIONS

- * TAP "RUN" AND THE PLAYER WILL RUN.
- * PUSH "JUMP/THROW" AND THE PLAYER WILL JUMP OR THROW.
- * HOLD "JUMP/THROW" BUTTON DOWN TO INCREASE ANGLE OF JUMP OR THROW.
- * IF YOU DO NOT QUALIFY IN AN EVENT THE GAME IS OVER.

EVENTS

I. 100m DASH:

KEEP TAPPING "RUN" TO INCREASE SPEED.
DISQUALIFICATION FOR 3 FALSE STARTS.

II&III. LONG JUMP & JAVELIN THROW:

KEEP TAPPING "RUN" TO INCREASE SPEED.

PUSH "JUMP/THROW" AT PROPER POSITION AND HOLD TO CONTROL

ANGLE.

IV. <u>110m HURDLE</u>:

TAP "RUN" TO INCREASE SPEED OF RUNNER. PRESS "JUMP" TO CLEAR HURDLES.

V. HAMMER THROW:

PRESS "RUN" AND RELEASE.
PRESS "THROW" AT PROPER POSITION.
HOLD TO DETERMINE ANGLE OF THROW.

VI. <u>HIGH JUMP</u>:

PUSH "RUN" AND RELEASE.
HIT "JUMP" AT PROPER POSITION.
CHANGE ANGLE OF JUMP BY USING "JUMP" BUTTON AS OFTEN AS
YOU LIKE.

OPTIONAL DIP SWITCH SETTINGS

Dip Switch No.1 (8P Dip Switch) Credits

Coin	Plays	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
1 1 1 1 1 2 2 2 3 3 3 4 4	1 2 3 4 5 6 7 1 3 5 1 2 4 1 3	0ff 0n 0ff 0n 0ff 0n 0ff 0n 0ff 0n 0ff	Off Off On Off Off On Off On Off On	Off Off Off On On On Off Off Off On On	Off Off Off Off Off Off On On On On	Off On Off On Off On Off On Off On Off	Off Off On Off Off On Off On Off On	Off Off Off On On On Off Off Off On On	Off Off Off Off Off Off On On On On On

2. Dip Switch No.2 (8P Dip Switch)

NUMBER OF EVENT ADVANCEMENT (If disqualified in previous event)

NUMBER OF EVENTS	SW1	SW2
One	Off	Off
Two	On	Off
Three	Off	On
Four	On	On

GAME TYPE

STYLE	SW3	PLAYERS
Table	Off	1 thru 4 Players
Upright	On	1 thru 4 Players

2. Dip Switch No. 2 continues

SW4 NOT IN USE

RANKING

MEMORY AT POWER UP	SW5
Data entered remains	0ff
Data entered erased	0 n

LEVEL OF DIFFICULTY

OPTIONS	SW6	SW7
Easy	Off	Off
Normal	On	Off
Hard	Off	On
Difficult	On	On

AUDIO ATTRACTION

MUSIC MODE	SW8
MUSIC ON	0 n
MUSIC OFF	0ff

INSTALLATION

YOUR GAME WAS SHIPPED FROM THE FACTORY IN READY-TO-PLAY CONDITION.

A BRIEF INSPECTION IS SUGGESTED BEFORE THE MACHINE IS REMOVED FROM THE CARTON. IF THERE IS DAMAGE TO THE SHIPPING CARTON, CONTACT THE FREIGHT CARRIER FOR CLAIM PURPOSES. EXTERNAL DAMAGE COULD INDICATE POSSIBLE DAMAGE TO THE CABINET AND/OR ELECTRONICS COMPONENTS.

AFTER THE CARTON HAS BEEN SATISFACTORILY INSPECTED, REMOVE THE MACHINE FROM THE SHIPPING CARTON.

EXAMINE THE INTERIOR OF THE GAME FOR DISCONNECTED WIRES, CABLES OR HARNESSES. MAKE SURE THE ELECTRONIC DEVICES ARE SECURELY MOUNTED IN THEIR SOCKETS, ETC. RECORD THE GAME SERIAL NUMBER, SINCE IT WILL BE REQUIRED FOR REFERENCE AND SERVICING.

ELECTRICAL REQUIREMENTS

Unless otherwise specified, this game is set to operate at 110 Volts A.C. (Refer to 110/220 VAC Conversion Instructions). Power supply chassis schematic information and parts list are included in this Manual.

110/220 VAC CONVERSION INSTRUCTIONS

THIS GAME CONTAINS A HARNESS CONFIGURATION WHICH ALLOWS THE MACHINE TO BE OPERATED FROM EITHER A 110 VAC OR 220 VAC, 50 Hz OR 60 Hz power source. ALL GAMES SHIPPED FROM CENTURI, INC., ARE IN THE 110 VAC CONFIGURATION. TO CHANGE TO THE 220 VAC CONFIGURATION FOLLOW THE PROCEDURE BELOW.

FIRST: UNPLUG THE MACHINE FROM THE WALL OUTLET TO

COMPLETELY ELIMINATE SHOCK HAZARDS.

SECOND: REMOVE THE 110 VAC PLUG FROM THE AC POWER CORD AND REPLACE WITH A 220 VAC PLUG.

ATTACH THE GREEN WIRE FROM THE AC CORD TO

THE GREEN SCREW OF THE 220 VAC PLUG.
ATTACH THE WHITE WIRE (NEUTRAL) AND THE
BLACK WIRE (HOT) OF THE AC CORD TO THE

220 VAC PLUG.

THIRD: REMOVE THE SINGLE 3 AMP SLOW-BLOW FUSE FOUND IN THE A.C. DISTRIBUTION BRACKET, AND INSTALL TWO, 1.5 AMP SLOW-BLOW FUSES. NEXT, CUT THE #18 AWG, WHITE JUMPER WIRE AT BOTH ENDS OF


THE FUSE HOLDER AND REPLACE THE COVER.

FOURTH: ON THE GAME POWER TRANSFORMER, LOCATE THE "ORANGE" JUMPER PLUG WHICH IS MARKED, 110 VAC. UNPLUG THE "ORANGE" JUMPER, AND PLUG IN THE "RED" JUMPER PLUG MARKED 220 VAC.

TO REVERT BACK TO 110 VAC, REPLACE THE COMPONENTS ORIGINALLY REMOVED FROM THE PROCEDURE STEPS ABOVE.

***NOTE: THE COMMON SIDE OF THE A.C. LINE MUST NOT BE FUSED IN THE 110 VAC CONFIGURATION, REPLACE THE #18 AWG. WHITE JUMPER WIRE.

(REFER ALSO TO THE 110/220 VAC POWER INTERCONNECT DIAGRAM)



ROUTINE MAINTENANCE & SERVICE

BECAUSE OF THE SOLID STATE ELECTRONIC CIRCUITRY, THIS MACHINE SHOULD REQUIRE VERY LITTLE MAINTENANCE, AND ONLY OCCASSIONAL ADJUSTMENT. HOWEVER, IT IS NECESSARY TO TAKE STEPS TO INSURE THIS.

THE VOLUME CONTROL IS LOCATED ON THE PRINTED CIRCUIT BOARD AND CAN BE ACCESSED THROUGH THE REAR CABINET DOOR.

THE VIDEO MONITOR HAS BEEN PROPERLY ADJUSTED BEFORE SHIPPING. OCCASSIONALLY MINOR ADJUSTMENTS ARE NECESSARY. TECHNICAL INFOR-MATION, ALONG WITH SCHEMATICS, CAN BE FOUND IN THIS MANUAL. ADJUSTMENT CONTROLS FOR THE MONITOR ARE LOCATED ON THE REAR OF THE MONITOR.

"DO NOT MAKE ANY ADJUSTMENTS ON THIS MACHINE WHILE THE POWER IS ON!"
THIS MACHINE SHOULD ONLY BE ADJUSTED BY A "QUALIFIED" TECHNICIAN.

FOR SERVICE INFORMATION, CONTACT:

CENTURI, INC.

CUSTOMER SERVICE DEPARTMENT

#800-327-7710 (OUTSIDE THE STATE OF FLORIDA)

#(305) 558-5200 (IN FLORIDA)

POWER SUPPLY

THE COMPUTER BOARD IN THIS GAME OPERATES MOST EFFICIENTLY AND RELIABLY WHEN THE POWER SUPPLY IS SET SO THE VOLTAGE ON THE BOARD IS 5.0~Volts, $\pm~0.1~\text{Volt}$. To check this, place a meter across 5~Volts and ground, at the edge connector. If necessary, adjust the screwdriver control on the power supply, so the meter reads between 4.9~And~5.1~Volts.

CABINET FRONT VIEW




FIGURE-2

CABINET FRONT VIEW

PARTS LIST

ITEM	PART NUMBER	DESCRIPTION
1	302-2705	MARQUEE HOLDING BRACKET
2	802-3113	MARQUEE, TRACK & FIELD
3	302-2846	MARQUEE LOWER HOLDING BRACKET
4	403-1171	SPEAKER, 8 OHM, 6 WATT, 5¼ IN. RD.
5	804-3133	MONITOR BEZEL, TRACK & FIELD
6	605-0975	VIEWING GLASS
7	302-2844	FRONT GLASS HOLDING BRACKET
	302-2845	FRONT GLASS REAR HOLDING BRACKET (NOT SHOWN)
8	701-1170	WHITE PUSH BUTTON
9	701-1171	RED PUSH BUTTON
10	701-1181	DARK BLUE PUSH BUTTON
	409-1163	SWITCH W/HOLDER
	103-0951	PAL NUT
11	801-3093	LEFT SIDE DECAL, TRACK & FIELD
12	009-4697	COIN DOOR
13	801-3094	RIGHT SIDE DECAL, TRACK & FIELD
14	801-3095	CONTROL PANEL OVERLAY
15	402-1511	A.C. POWER CORD, 12FT.

12

STD SINGLE COIN DOOR W/2 COIN ENTRY
MATES | HEATTREAT FINISH

DOWN B. MUR. BATE B. SCALE | PART NO. 96-4697

WILL PIN 15-8291-02

QC, APV'D

PROD. APV'D OTY. ASSEMBLY NO

HIALEAH, FLORIDA 33014


REV. ECN REVISION	FIGURE 3	
В		

(3)

STANDARD COIN DOOR WICO P/N 15-8281-01

PARTS LIST

ITEM NO.	Wico P/N	Description	Req'd
1	15-8039	Door Frame	1
2	15-8038	Door	1
3	30-9125	Hinge	1
4	15-8117	Nameplate, Centuri	1
5	15-8074	Coin Entry Plate	7
6	15-8072	Push Button, Cover	2
7	26-0583	Label, Push to reject, 25¢	2
8	15-8071	Push Button	2
9	30-7722		2
10	15-8084	Compression Spring	2
11	15-8075	Reject Lever	2
12	15-9419	Coin Chute	2
13		Lamp Holder Ass'y	2
14	21-0044	Miniature Lamp, 6V	2
	15-8083	Coin Return Door	2
15 16	15-8081	Coin Box	2
16	15-8092	Guard	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
19	23-1347	Coin Switch	2
20	15-8043	Switch Cover	
21	15-1255	Slam Switch	1
22	31-4015	Plastic Coin Acceptor, 25¢	2
23	15-8086	Coin Acceptor Retainer	2
24	30-1790	Washer, .255 ID x .625 OD x .037" Thick	2
25	30-0931	"E" Ring, ¼"	2
26	30-7372	Extension Spring	2
27	31-4550	Coin Counter, 6VDC, W/Brkt	1
28	15-8113	Bracket	1
29	23-1370	Service Switch	1
31	34-1855	Lock Ass'y, 5/8"	1
32	55-2905	Lock Cam Ass'y	1
33	55-2909	Lock Cam Plate	2
34	30-3001	M.S. Pan Hd, Phil.#6-32 x ½*lg	
35	30-0164	M C E/Ud Dbil #6-32 x 3/19	9 2
36	30-1921	M.S. F/Hd, Phil.#6-32 x 3/8"1g	2
30		Washer, .165 ID x .475 OD x .032" Thick	2
37	30-2826	M.S. Fil/Hd. Phil.#6-32 x $7/16$ "lg	12
38	30-2818	M.S. Rd/Hd. #4-40 x 7/8" 1g	2
39	30-1213	Hex. Nut, #4-40	2
40	30-2778	M.S. Fil/Hd. Phil.#6-32 x ½"lg	2
41	30-2833	M.S.Pan/Hd. Phil. #6-32 x 3/16"lg	9
42	23-1348	Wire Form (Coin Switch)	2
43	97-0007	Door Cable Ass'y	1
44	26-3125	Double Sided Tape (3M) ½"x½"	ī
	15-8107	Key Hook	1
'	,		-





Power Supply PSR-703AE PARTS LIST (414-2020)

Symbol	Description	Qty
D1	Bridge Stack, RB-40, 600V	1
D4,D5	Fast Recovery Diode, 1GH62	2
D2,D3,D7,	Switching Diode, 181554	6
D8,D9,D10		
D11	Fast Recovery Diode, S5KC2OH	1
D12,D13	Fast Recovery Diode, 10DF1	2
D16	Schotky Barrier Diode, C8P030	1
ZD1	Zener Diode, 05Z, 5.6V, 500mw	1
Q1,Q2	Power Transistor, 2SC2553	2 1 2 2 1
Q3 Q4,Q5	Power Transistor, 2SC2831	Ţ
Q6,Q7	Transistor, 2SA564R Transistor, 2SC828R	2
IC 1	Switching Control, UPC494C	2
IC 2	Regulator IC, 7805 (1A)	1
T1	Power Transformer, SM2335	1
T2,T3	Driver Transformer, SM2215B	1 2 1
T4	Driver Transformer, SM2215B Power Transformer (Sub) SM2376	1
CH1	Choke Transformer, SM2219	ī
CH2	Choke Transformer, SM2376B	ī
CH4	Choke Transformer, SM2366	1
L1	AC Line Filter, ELF-18D-112	1
TH1	Power Thermistor, TD18-010	1
C2,C3	Ceramic Capacitor, 2200pf, AC400V	1 2 1
C1	Capacitor, Metalized, 0.033mf, 600V	
C6	" , 0.47mf, 50V	1
C15	, myrar, u.uuliit, buv	1
C9,C13,C34,	" , 0.01mf	5
C35,C37 C12	II II O OOA7m£	
C31	" , 0.0047mf " , 0.1mf	1
C18	Capacitor, Ceramic, 50pf, 50V	1
C7	", 330pf, 1kv	1
C16,C28	" , 0.01mf, 16V	2
C20,C23	" , 0.1mf, 16V	2
C14	Capacitor, Electrolytic, 4.7mf, 25V	1 2 2 1
C10	" , 10mf, 16V	ī
C11	" , 100mf, 16V	ī
C21	" , 220 mf, 35V	1
C22	" , 470mf, 16V	1
C17,C19	" , 470mf, 25V	2
C29,C30	, 22UUMT, 1UV	2
C4, C5	, 220MT, 180V	2
R31 R34	Resistor, Cement, 270 ohm, 5W	2 2 2 1
R9	", Oxide Metal Film, 33 ohm, 3W	
R3	, 470 Onm, 2w	1
NO	" " " , 100 ohm,2W	1

POWER SUPPLY PSR-703AE PART LIST (414-2020)

R36,R37,R39 Resistor, Carbon, 5.1 ohm, 1/2 W 2 R6,R7 "", 12 ohm, 1/2 W 2 R1,R2 "", 150K ohm, 1/2 W 2 R8 "", 330K ohm, 1/2 W 1 R12 "", 150 ohm, 1/4 W 1 R10 "", 1K ohm, 1/4 W 1 R11 "", 10 ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 1 R22 "", 180 ohm, 1/4 W 1 R22 "", 120 ohm, 1/4 W 1 R22 "", 180 ohm, 1/4 W 1 R22 "", 15K ohm, 1/4 W 1 R23 "", 15K ohm, 1/4 W 1 R29 "", 15K ohm, 1/4 W 1 R29 "", 15K ohm, 1/4 W 1 R29 "", 15K ohm, 1/4 W 1
R4,R5
R12 R10 "", 150 ohm, 1/4 W 1 R11 "", 10 ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 2 R30 "", 180 ohm, 1/4 W 1 R22 "", 220 ohm, 1/4 W 1 R32 "", 1K ohm, 1/4 W 1 R32 "", 1, 1K ohm, 1/4 W 1 R26 "", 1.8K ohm, 1/4 W 1 R27 R30 "", 1, 1, 1, 1, 2, 3, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4,
R12 R10 "", 150 ohm, 1/4 W 1 R11 "", 10 ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 2 R30 "", 180 ohm, 1/4 W 1 R22 "", 220 ohm, 1/4 W 1 R32 "", 1K ohm, 1/4 W 1 R32 "", 1, 1K ohm, 1/4 W 1 R26 "", 1.8K ohm, 1/4 W 1 R27 R30 "", 1, 1, 1, 1, 2, 3, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4,
R12 R10 "", 150 ohm, 1/4 W 1 R11 "", 10 ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 2 R30 "", 180 ohm, 1/4 W 1 R22 "", 220 ohm, 1/4 W 1 R32 "", 1K ohm, 1/4 W 1 R32 "", 1, 1K ohm, 1/4 W 1 R26 "", 1.8K ohm, 1/4 W 1 R27 R30 "", 1, 1, 1, 1, 2, 3, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4,
R12 R10 "", 150 ohm, 1/4 W 1 R11 "", 10 ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 2 R30 "", 180 ohm, 1/4 W 1 R22 "", 220 ohm, 1/4 W 1 R32 "", 1K ohm, 1/4 W 1 R32 "", 1, 1K ohm, 1/4 W 1 R26 "", 1.8K ohm, 1/4 W 1 R27 R30 "", 1, 1, 1, 1, 2, 3, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4,
R10 R11 "", 1K ohm, 1/4 W 1 R40 "", 3.9K ohm, 1/4 W 1 R35 "", 5.1K ohm, 1/4 W 1 R18,R27 "", 100 ohm, 1/4 W 2 R30 "", 180 ohm, 1/4 W 1 R22 "", 220 ohm, 1/4 W 1 R32 "", 1K ohm, 1/4 W 1 R32 "", 18K ohm, 1/4 W 1 R26 "", 1.8K ohm, 1/4 W 1 R27 R28 "", 10K ohm, 1/4 W 1 R29 "", 15K ohm, 1/4 W 1
R11
R40
R35
R18,R27 " , 100 ohm, 1/4 W 2 R30 " , 180 ohm, 1/4 W 1 R22 " , 220 ohm, 1/4 W 1 R32 " , 1K ohm, 1/4 W 1 R26 " , 1.8K ohm, 1/4 W 1 R12,R14 " , 5.1K ohm, 1/4 W 2 R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R30 " , 180 ohm, 1/4 W 1 R22 " , 220 ohm, 1/4 W 1 R32 " , 1K ohm, 1/4 W 1 R26 " , 1.8K ohm, 1/4 W 1 R12,R14 " , 5.1K ohm, 1/4 W 2 R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R22 " , 220 ohm, 1/4 W 1 R32 " , 1K ohm, 1/4 W 1 R26 " , 1.8K ohm, 1/4 W 1 R12,R14 " , 5.1K ohm, 1/4 W 2 R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R32 " , 1K ohm, 1/4 W 1 R26 " , 1.8K ohm, 1/4 W 1 R12,R14 " , 5.1K ohm, 1/4 W 2 R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R28 " , 10K ohm, 1/4 W 1 R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R29 " , 15K ohm, 1/4 W 1 R23 " , 20K ohm, 1/4 W 1
R23 " , 20K ohm, 1/4 W 1
R19 ", 6.8K ohm, 1/4 W 1
R15,R16,R17,R33 " , 100K ohm, 1/4 W 4
R21 ", 150K ohm, 1/4 W 1
R25 ", 270K ohm, 1/4 W 1
R20 " , 390 ohm, 1/4 W 1
VR1 Semi-fixed resistor, GFD6-B 3K 1
RS1 Manganese Metal Wire, A-2145 1
RS2 Manganese Metal Wire, 1.0 Ø x 55m/m 1
F1 Fuse, 3 amp.
Fuse Holder, F-207





	AF 1	7899	A					times a		•••••					
	REV.						TIEN	1	N	Q	4	υj	6	7	σ
	\	-		-			418	\	22%	73 I	29 1	25"	271/2	112"	18"
	NO.						TIEM GTY PART NO.	401	22" 402-1526 INSULATED WIRE, WHITE 225WG 10 151/2" 402-1524 INSULATED WIRE, VIOLET, 220WG	23" 402-1525 INSULATED WIKE, GRAY, ZZAWG 11 25" 402-1521 INSULATED WIRE YELDW, ZZAWG	29 11402-1520 INSULATED WIRE, ORANGE, 22AWG 12 27" 402-1519 INSULATED WIRE, RED, 22AWG	25" 407 1523 [NSULATED WIRE, BLUE, 22ANG 13 11 401-1222 MALE PIN, MOLEX, 02-09-2116	27/4" 402-1572, INSULATED INIAE. GREEN ZZANG 14 20 401-1302 3/16" PUSH ON TERMINAL, ETC #095	112" 402-1517 INSULATE WIRE BLACK, 22AWG	18" 402-1521 INSULATED WIRE, YELLOW, 22AW.
		-	\vdash				7 76	401-1230	-/52	-152	153	162	-152	15	-152
							1	0	100	5	H	is H	2, 1	7	+1
							DESCRIPTION	128 Molex Plug # 03-04-2122	Neul	NSUL	Vsuck	NSUL	NSUL	Noul	Noon
	RE						10710	1 X+70	ATEL	ATEL	TEL 1	aTED	ATE	77.7	STED!
	REVISION						ž	9010	WIRE	Viik	WIRE	MIR	1 W//	NIEC	Whee
	Ž					8/1		- 20 0	HW.	5,61	ORAI	18	E. 61	BLA	$\gamma_{i'}$
						7.1		2.60	TE	14. Z	136	JF 2	SEEW.	ck,2	140
						OF		122	2.2/W	WAZE	22AW	2AW	22AW	24 W/	7:74×
						BILL OF MATERIALS	312	o	5/10	9 11	S /2	0/3	16 14	1/5	15
	ВҮ					TER	ITEM OTY DARTNO. DESCRIPTION	9 13" 402-1518 INSULATED WIRE, BROWN, 2ZAWG	15	25	27	1	80	15 A/R 417-1601 TY WRAPS 4"	
	ANGLES SHT. ME	HOLES	DECI	FR Uni		181	Y p	1/ 40	12. 45	140	100	40	40	7 4,	
1 0	ANGLES ±	S	DECIMALS 3 PL	Unless Otherwise Specified FRACTIONS + 1/32	101	5	RTA	2-151	2-15	2-/5	2-15	01-12	1-131	7-16	
	SENDS		2 PL 3 PL	nerwise	TOLERANCES		18	8	24 1	2/	19 1	22 M	92	0/	
		l +	I+ I+ !·	Speci	VCES		Desc	NSUL	JUSUL.	TRIPLY	vsul	TALE	116"8	マ	
	2, 1/2,	.00 01	.015	fied			RIP	160	ATES	9761	700	P11.1	usH c	NAM	
	J.M.	MATL'S.	NAN NAN		I		TON	NIRE,	WIR	WIRE	NIRE	(Jole)	NTO	35 4"	
	3.	.S. T	\ \ \ \ \					BEOV	61/10	YELL	PER	.20%	MINA	Ì	
			7780	Ω			,	VW 22	47,2	OW, 2:	22/	-09-2	1 ETC		
<	₹ ₽		7 1		1			346	ZAWG	AWG	9W6	116	1695		
	DATE 9-28		AN			8									
	DATE 9-28-83		EL_1	ě	i j	QC. APV'D									
	ω (a	НЕА.	HAR			ð									
	SCALE	HEAT TREAT	NES			PRO									
		AT.	5-7			O. AP									
	PART NO. 008-4914		TRAC	Ī		PROD. APV'D QTY.	\downarrow	\dashv		4					
	ÖpŠ	FINISH	¥ 7.	IALEA		OTY.		\							
	49	HS	17	Ĥ, FL		Ą	1	1		1					
	Ā		673	ORID		SSEME									
	2		CONTROL PANEL HARNESS- TRACK & FIELD, U/R	HIALEAH, FLORIDA 33014		ASSEMBLY NO									
	REV.		<i>እ</i> `	4		ō				1					



Centuri, Inc. ● 245 W. 74th Place ● Hialeah, Florida 33014 Telephone: 305-558-5200 • Telex: 803694 ● ANSB Centuri Licensed by Tehkan Ltd.

